

Dimpala™

MEERKAT™



TRADER®

# Push Button Comparison

Model	DIMPBD - White LED DIMPBD <sup>A</sup> - Amber LED	MEPBE - Blue LED MEPBE <sup>A</sup> - Amber LED	MEPBMW - White LED MEPBMW <sup>A</sup> - Amber LED
LED Function			
LED On with Load/Off with Load			
LED ON with Button Press (Flashes)			
LED OFF			
LED Always ON			

Notes:

<sup>1</sup> Programable

<sup>2</sup> White Cable Connected to Remote (DIMPBD - MEPBE)

<sup>3</sup> No Neutral Connected

<sup>4</sup> Red Cable Connected to Remote (DIMPBD - MEPBE)



Neutral Must be connected for SWITCH to operate



Neutral Must be Connected for LED to operate