



# INTERCONNECTABLE

ili

## WELCOME TO THE BEAR RANGE OF FULLY INTERCONNECTABLE WIRELESS SMOKE ALARMS

Wireless Ready Smoke Alarm Photoelectric smoke alarm Mains powered, wireless ready



## Wireless Smoke Alarm

Photoelectric Smoke alarm Wireless, (non removable) Lithium battery only



Order Code BESMOKEY10BW



BESMOKEY10WM

Wireless Remote To be used once smoke alarms are interconnected wirelessly



Order Code BESMOKEY10REM

GSM Electrical (Australia) Pty Ltd // Level 2, 142-144 Fullarton Road, Rose Park SA 5067 // P: 1300 301 838 E: service@gsme.com.au

# Ten out of Ten Smoke Alarm Features

#### Our new Bear BESMOKEY10 photoelectric mains-wired smoke alarm is packed with features.



## **BESMOKEY10 - Photoelectric Smoke alarm**

#### **Reliability:**

Mains powered smoke alarm supplied with 10 Year lithium battery.

#### **Choice of Interconnection:**

Hard-wired up to 24 units or Wireless up to 40 units.

Interconnectable with BESMOKEY10BW

#### Easy install:

Hinged base plate detaches and mounts to the ceiling.

#### Easy wiring:

Base plate comes with 4 large terminals with ample wiring room.



## **BESMOKEY10WM - Wireless module**

# Wireless interconnection requires **BESMOKEY10WM** wireless module.

**Simple to install:** Insert one wireless module into each smoke alarm you wish to wirelessly interconnect with.

**Easy pairing:** Press TEST on Master (3 times in 2 sec) and linked alarms to pair. See instructions for more detail.



## **BESMOKEY10REM - Remote**

**Convenient:** Works only with **BESMOKEY10** smoke alarms, fitted with the **BESMOKEY10WM** Wireless Module for easy control.

NET - connects the remote to the Master Alarm

 $\ensuremath{\text{LOCATE}}$  - returns alarms to normal other than the alarm which detected the smoke

HUSH - silences alarm mode for 10 minutes.

SOS - activates the smoke alarm network for one minute.



## **BESMOKEY10BW – Photoelectric, Battery only** Smoke Alarm

No wiring: Supplied with a non-removable Lithium 10 Year battery.

Wireless interconnection: Up to 40 other units

**Easy pairing:** Press TEST on Master (3 times in 2 sec) and linked alarms to pair. See instructions for more detail.

**Interconnectable:** With **BESMOKEY10** fitted with **BESMOKEY10WM** Wireless module.

#### See instructions and data sheets for more info.




Hinged base plate easily detaches



Clearly labelled easy to identify sensor wiring



Easy to insert wireless module



Easy to operate remote control



Aesthetically pleasing design

### CLICK BELOW TO FIND OUT MORE

Data Sheets www.gsme.com.au/uploads/downloads/ Data\_Sheets\_Bear.pdf

Flyer www.gsme.com.au/uploads/downloads/ Bear\_Flyer\_Wireless\_Ready.pdf

Instructions

ww.gsme.com.au/uploads/downloads/ BESMOKEY10\_Instructions.pdf