







Order Code: DIMPRX 'No Glow'

REPLACES THE NEED FOR A 2 GANG PLATE!



EQUALS

TRADITIONALLY A TWO (2) GANG SWITCH PLATE IS REQUIRED WITH A SWITCH MECH AND A DIMMER KNOB DIMPR ALL-IN-ONE SOLUTION! ONLY 1 GANG PLATE REQUIRED WITH DIMPR IT IS A SWITCH THAT CONTROLS ON/OFF & DIMMER CONTROL



Trader's NEW Dimpala PUSH Dimmer is mechanically switched and provides optimised dimming of LED lamps and drivers.

- **NO SWITCH NEEDED!** DIMPR is a DIMMER and a SWITCH in ONE!
- 220-240Vac / 50Hz / 2W Min / 400W Max / <1% to > 95% (load dependent).
- Suitable for LED, incandescent and 12V dichroic lamps.
- Minimum dimming level, typically almost 0%.
- Push switch configuration with terminals similar to a standard switch for easy wiring.
- Integrated switch replaces the need for an additional control switch.
- Soft start for improved lamp & driver life.
- Thermal protection via NTC (negative temperature control).
- DIMPR is suitable for use with Australian wall plate apertures including Trader, HPM[#] & Clipsal^{*}.
- DIMPRKBS kit is suitable for use with Clipsal Saturn*.

Features include:

REPLACES THE NEED FOR A 2 GANG PLATE!



Dual control knob

Inner button for ON/OFF. Outer dial for dimming.



Wires like a mech

Easy installation. Note: No common terminal. Terminal 1 for active in. Load terminal for lamp, etc.



Saturn* style knob available









DIMPR knob on a white DIMPRKBS on glass-loo switch plate (example) switch plate (example)



Unless otherwise stated the identified trademarks and copyrights are the property of GSM Electrical (Australia) Pty Ltd. *HPM is a registered trademark of Legrand Australia Pty Ltd.

*Clipsal and Saturn are registered trademarks of Schneider Electric

(Australia) Pty Ltd. Reference is made for suitability of use only.

GSM Electrical (Australia) Pty Ltd, the TRADER brand and it's products, have no endorsement or affiliation with Schneider Electric Pty Ltd. or Legrand Australia Pty Ltd.



PUSH BUTTON ROTARY DIMMER DIM = Dimmer / P = Push / R = Rotary "No switch required"

Also available: Saturn* Style Accessory Knob Order Code:

DIMPRKBS PUSH BUTTON ROTARY DIMMER KNOB DIM = Dimmer / P = Push / R = Rotary / KB = Knob / S = Saturn style*





100 Years of Gerard Electrical Tradition





